

## Technical Note : How To Set-up Modem For EsofWIN/5

Written : Ng MW Date: Jul 15, 1998

=====  
This FAQ concerns problems you might encounter with EsofWIN's modem version.  
This FAQ does not attempt to provide set-up instructions. For these, please refer to the manual.

1. How to wire up the cable from communicator (EL70B) to modem?
2. How can I set the modem to auto-answer in advance before placing the modem at the remote site?

=====  
**1. How to wire up the cable from communicator (EL70B) to modem?**

Cable Wiring from EL70B to Modem

EL70T (male9)	Modem (male 25)
2-----	----- 2
3-----	----- 3
5-----	----- 7
	4-+
	5-+
	6-+
	8-+
	20-+

-----  
**2. How can I set the modem to auto-answer in advance before placing the modem at the remote site ?**

- (a) Connect the modem to the PC COM1 or COM2.
- (b) Launch a terminal program - such as hyperterminal in Windows 95 or Terminal in WIN 3.1.
- (c) Set to 2400,8,1,N (the baud rate does not really matter).
- (d) Type AT <ENTER>.
- (e) You should see OK reply from the modem, if not, check wiring or COM port.
- (f) Type AT&W0 <ENTER>
- (g) Type AT&W0 <ENTER>
- (h) You should see the LED label AA lights up.
- (i) Done.